

4LDR | 6LDR DOWNLIGHT

INSTALLATION INSTRUCTIONS



WARNING:

- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Make sure all electrical power is turned off while installing the fixture.
- This luminaire must be adequately grounded for protection against shock hazards and to assure proper operation.
- Disconnect power before servicing.
- LEDs are ESD (Electro Static Discharge) sensitive devices that can be easily damaged if the proper ESD mitigating steps are not taken.
- LEDs are very sensitive to mechanical damage. Caution must be taken to avoid damage to the LEDs.
- ESD or mechanical damage voids all warranties.
- Suitable for wet location under covered ceiling.

CONTENTS

STEP 1 MOUNTING PAN.....	1	STEP 4 DOWNLIGHT HEAD.....	4
STEP 2 ELECTRICAL CONNECTIONS.....	2	STEP 5 INTEGRAL TEST SWITCH OPTION.....	5
STEP 3 JUNCTION BOX.....	3		

TOOLS REQUIRED

Ceiling cutout tool

CEILING CUTOUTS


4LDR: 5" standard flange | 6LDR: 6-1/2" standard flange

STEP 1 MOUNTING PAN


A. Attach mounting hardware to fixture pan (remodel skip this step)

NEW CONSTRUCTION MOUNTING


F1 (2) Universal bar hangers
mount to t-bar or nailer bar
PN 92039666



F1 with IC-rated enclosure



B. Install pan assembly




4LDR | 6LDR DOWNLIGHT

INSTALLATION INSTRUCTIONS

STEP 2 ELECTRICAL CONNECTIONS


A. Connect junction box to conduit.

NEW CONSTRUCTION & REMODEL





IC-RATED ENCLOSURE

(Mounting hardware not shown)



WIRING DIAGRAM

Make electrical connections in accordance with NEC and local codes.




4LDR | 6LDR DOWNLIGHT

INSTALLATION INSTRUCTIONS


STEP 3 JUNCTION BOX

A. Snap in j-box to install (mounting hardware not shown).

NEW CONSTRUCTION



REMODEL




4LDR | 6LDR DOWNLIGHT

INSTALLATION INSTRUCTIONS

STEP 4 DOWNLIGHT HEAD


A. Prepare downlight head for installation



4LDR | 6LDR DOWNLIGHT

INSTALLATION INSTRUCTIONS

B. Secure downlight head



STEP 5 INTEGRAL TEST SWITCH OPTION

